
BARCODE SCANNER TYPES

HANDHELD COMPUTER ALL-IN-ONE SCANNER



Zebra TC20 Not to Scale



wifi or data provider just as you would on a smart phone.



Use Mobile Chrome browser to access SPS Core and Mobile Module. Chrome is browser of choice for SPS.



Rugged or impact resistant cases or similar rugged models are available



Requirement: Configure scanner to append an enter/return keystroke after each scan. This ensures automatic submission or allowing scans to fill in one per line in a text area.



Zebra CS4070 Not to Scale



RECOMMENDATIONS

- Zebra TC20 (Wifi Only) • Zebra TC25
- www.zebra.com



RECOMMENDATIONS

- Zebra CS4070

COMPANION SCANNER BLUETOOTH OR BATCH MODE

This scanner requires a connection to a computer, tablet, or smart phone.



Bluetooth Mode: Scanner acts as a wireless keyboard when connected to a phone or tablet allowing the scans to load into the text fields in SPS.



Batch Mode: Scanner will store all the scans to itself in a file. The file and Scans are retrieved by plugging the scanner into a computer via USB.



Configuration: Any configuration is applied through various setup barcodes

Requirement: Scanner settings need to allow the scan/data transmission rate to be slowed for proper use with a mobile bowser and SPS Mobile Module.

www.zebra.com Saveo Pocket Scan www.saveoscan.com